104KEY HIGH-END MECHANICAL KEYBOARD

PRODUCT USER GUIDE



USER GUIDE

## **Function Key Combinations**

- Hold for 5s to restore factory defaults Fn ESC
- **Change Lighting Modes** Fn DEL
- **Solid Color Breathing Cycle** Fn
- Fn INS **Change Interactive Lighting Modes**
- Fn Switch to Per Key lighting mode
- **Change Colors**

Fn

Fn

Fn

Fn

Fn ٠

٠

•

- Fn BACK SPA Set Per Key Lighting
- 4 **Decrease Backlighting Animation Speed** Fn

Macro Key

Fn + Y + + Fn + F11

- **Increase Backlighting Animation Speed Increase Backlighting Brightness** Fn
- •
- **Decrease Backlighting Brightness**
- Fn + = Lock or Unlock Win Key
- Fn Toggle Macro Keys (Y,U,I,O,P)
- Increase Screen Fn FI Brightness
- Decrease Screen Fn F2 F3
- **Volume Down** F4 Fn Volume Up
- **♣** F11 **Set Macro Recording**
- F12 **Lock All Keys** Fn

Toggle 6 key Rollover / Full key Rollover

- Fn PGDW \* Side LED Backlight Animation
- \* Side LED RGB Mode
- \* Side LED Single Color Mode ÷
- Fn \* Side LED Increase Speed

\* Side LED Decrease Speed

\* Side LED Decrease Brightness

Fn \* Side LED Increase Brightness



DESIGNED BY HEXGEARS IN GERMANY