



In the Box

Large Medium Small

Replaceable Ear Tips

NanoPods and Charging Case

USB-C Cable

A Closer Look

LED Indicator/ Microphone

Touch Sensor

Charging Contacts

LED Indicator

Charging

Place these earbuds into the case to charge

- Charging (Indicator is red)
- Fully Charged (Indicator is off)

The LED indicator will flash when charging:

- ● ● ● <25%
- ● ● ● ● <50%
- ● ● ● ● ● <75%
- ● ● ● ● ● ● <100%

Connect the USB-C cable into the charging port to charge the case. The case's indicator will flash momentarily to indicate a low battery.

Powering On

For the first use, place the earbuds back into the case then take out of the case; this will activate the earbuds.

To turn on, place the earbuds into the case then take the earbuds out of case. **To turn off**, place the earbuds into the case.

If the LEDs do not turn on when the earbuds are removed from the case, charge the case then try again. In the event that the earbuds do not pair together, perform the Manual Reset function.

Bluetooth Pairing

To connect the earbuds to your smartphone, go to settings then select the Bluetooth page. Look under 'available devices' and connect to "NanoPods".

Note: The earbuds will go into pairing mode automatically when taken out of the case.

Touch Button Functions

Left Earbud: Right Earbud:

Decrease Volume: Press Once Increase Volume: Press Once

Previous Selection: Press Twice Next Selection: Press Twice

Voice Assistant: Press & Hold 2 Sec. Pause/ Play: Press & Hold 2 Sec.

Answer Call: Press Once Answer Call: Press Once

Decline Call: Press Twice Decline Call: Press Twice

Hang Up Call: Press & Hold 2 Sec. Hang Up Call: Press & Hold 2 Sec.

Manual Reset

Only do this function experiencing issues that are not solved by simply turning the earbuds on/off, or by placing them back into the case.

1. Remove both earbuds from the case.
2. Hold down the left and right sensor for 9 seconds. Both earbuds will flash blue three times, then flash red and blue before resetting.
3. Place both earbuds back into the case to activate the earbuds and take both earbuds out of the case to re-pair the earbuds.
4. Reconnect the smartphone to your earbuds and continue to use.

Notes

**To use Siri or Google Assistant, you must have a phone that is compatible with one of those two voice assistants (iOS or Android, respectively).*

***You must be within Bluetooth® range to use Siri or Google Assistant via your Wireless Earbuds.*

Your Wireless Earbuds will not work with Siri or Google Assistant if the assistant is not first enabled within the settings on the phone. For more information, see your phone's user manual.

For additional user materials and warranty information, please visit alteclansing.com

FIRST

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FOLLOW US ON

#myalteclansing