

**X**HOVER-1™

**SWITCH**



OPERATION MANUAL  
H1-SWCH

# HELMETS SAVE LIVES!

Always wear a properly fitted helmet that complies with CPSC or CE safety standards when you ride your scooter.



**Correct Fitting:**  
Make sure your helmet covers your forehead.



**Incorrect Fitting:**  
Forehead is exposed and vulnerable to serious injury.

# **WARNING!**

## **PLEASE READ THE USER MANUAL THOROUGHLY.**

**Failure to follow the basic instructions and safety precautions listed in the user manual can lead to damage to your Switch, other property damage, serious bodily injury, and even death.**

Thank you for purchasing the Hover-1 Switch. Please read all instructions carefully before using and retain this manual for future use and reference.

This manual applies to the Hover-1 Switch.

- In order to avoid dangers that are caused by collisions, falls, and loss of control, please learn how to ride the Switch safely.
- You can learn operating skills by reading the product manual and watching videos.
- This manual includes operating instructions and precautions, and users must read it carefully and follow the instructions.
- All users are responsible for any consequences caused by violating warning contents or prompt operations. Hover-1 can not be held liable.

### **ATTENTION**

1. Use only the supplied charger with this scooter.

Charger Manufacturer: SHENZHEN HYLETON TECHNOLOGY CO.,LTD

Model: HLT-118C-2941000

2. The operating temperature range of the charger is 32° F-104° F (0-40° C).
3. The operating temperature range of the Switch is 32-104° F (0-40° C).
4. Do not ride on icy or slippery surfaces.
5. Read the operation manual and warning labels before riding.
6. Store the Switch in a dry, ventilated environment.
7. When transporting the Switch, avoid violent crashes or impact.

## **LOW TEMPERATURE WARNING**

Low temperatures will affect the lubrication of moving parts inside the Switch, increasing internal resistance. At the same time, in low temperatures, the discharge capacity and the capacity itself of the battery will be significantly decreased.

Use caution when riding the Switch in cold temperatures (below 40 degrees F).

Doing so may increase the risk of mechanical failures of the Switch, which may lead to damage to your Switch, other property damage, serious bodily injury and even death.

## **SAFETY INSTRUCTIONS**

- Keep the Switch away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the Switch if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the Switch.
- Do not use the Switch if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by the manufacturer. Improper repair voids the warranty and may place the user at serious risk.
- Do not puncture or harm the exterior surface of the product in any way.
- Keep the Switch free from dust, lint, etc.
- Do not use your Switch for anything other than its intended use or purpose. Doing so may damage the Switch or lead to property damage, injury or death.
- This product is not a toy. Keep out of reach of children.
- Do not expose batteries, battery pack, or batteries installed to excessive heat, such as direct sunlight, or open flame.
- Do not allow hands, feet, hair, body parts, clothing or similar articles to come in contact with moving parts, wheels or drive-train, while the Switch is running.
- Do not operate, or allow others to operate, the Hover-1, until the

user understands all instructions, warnings and safety features described in this manual.

- Check with your doctor if you have a medical condition that could affect your ability to use the Hover-1 Switch.
- Persons with head, back or neck ailments or prior surgeries to those areas of the body are not recommended to use this Hover-1 Switch.
- Do not operate if you are pregnant, have a heart condition, or have both.
- Persons with any mental or physical conditions that may make them susceptible to injury or impair their physical or mental capabilities to recognize, understand and perform all of the safety instructions and to be able to assume the hazards inherent in unit use, should not use the Hover-1 Switch.



## NOTES:

In this manual, the above symbol with the word "NOTES" indicates instructions or relevant facts the user should remember prior to using the Switch.



## CAUTION!

In this manual, the above symbol with the word "CAUTION" indicates a hazardous situation which, if not avoided, can cause minor or moderate injury.



## WARNING!

In this manual, the above symbol with the word "WARNING" indicates a hazardous situation which, if not avoided, can cause death or serious injury.

## SERIAL NUMBER

Please keep the serial number on file for warranty claims as well as proof of purchase.



## WARNING!

**WARNING:** Prolonged Exposure to UV Rays, Rain and the Elements  
May Damage the Enclosure Materials.  
Store Indoors When Not in Use.


# INTRODUCTION

The Switch is a personal transporter. Our technology and production processes are developed with strict testing for each Switch. Operating the Switch without following the contents of this manual may lead to damage to your Switch, or bodily injury.

This manual is designed to give you the information you need for the safe operation and maintenance of your new Switch. Please read it thoroughly before riding your Switch.

## PACKAGE CONTENTS

- Hover-1 Switch Electric Skateboard
- Scooter Assembly
- Remote
- USB Cable
- Operation Manual
- Wall Charger
- Toolkit




## SCOOTER

1. Scooter Attachment
2. Height Adjustment Latch
3. Remote Insert Slot
4. Brake Lever
5. Acceleration Lever


## SKATEBOARD

1. Skate Deck
2. Attachable Trucks
3. Power Button
4. Charge Port
5. Brushless Hub Motor
6. Protective Sleeve



## REMOTE FEATURES

1. Throttle/Brake
2. Power Button
3. Reverse Button
4. Pairing Led Indicator
5. Scooter Battery Indicator
6. Remote Battery Indicator
7. USB Charge Port
8. Scooter Docking Port



## WARNING

Any Switch that does not work properly can cause you to lose control and fall. Inspect the entire device thoroughly before every ride, and do not ride it until any problems have been corrected.

## SPECIFICATIONS

Model:	H1-SWCH
Net Weight:	19.5 lbs (8.87 kg)
Max Supported Weight:	132 lbs (60 kg)
Min Supported Weight:	44 lbs (20 kg)
Max Speed:	Scooter - 9mph (15 km/h) Skateboard - 7mph (12 km/h)
Max Distance Range:	Up to 6 miles (9.8 km)
Battery Type:	Lithium-ion
Motor Power:	90W Brushless
Battery Voltage:	25.2 V
Battery Capacity:	2.0 Ah
Charge Time:	Up to 2.5 hours
Power Requirement:	AC 100-240V, 50/60Hz
Product Dimensions:	
Scooter:	32.9 in X 16.1 in X 39.8 in (84 cm x 41 cm x 101 cm)
Skateboard:	27.6 in X 8.7 in X 6.3 in (70 cm x 22 cm x 16 cm)
Product Weight:	24.6 lbs (11.2kg)
Board size :	26.8 inch x 8.3 inch
Wheel Size:	Scooter Assembly: 4.7 inch Skateboard: 2.75 inch
Remote Battery:	220 mAh
Remote Connectivity:	2.4G wireless connection
Remote Charging Time:	Up to 2 hours

# PARTS LIST

**A.** Hoverboard Base+Scooter Attachment

**B.** Skateboard Attachment







**C.** Remote Control

**D.** USB cable

**E.** Wall Charger

**F.** Handlebars

**G.** Toolkit






# CONVERTING YOUR SWITCH

## PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY


When opening the box you will find the Switch is currently in skateboard form and the scooter attachment is separate. Follow these steps in order to turn your skateboard into a scooter.

### REPLACING THE FRONT WHEELS

On the underside of the skateboard, press and hold the release lever behind the front axle, then slide the front wheel assembly away from the skateboard deck.




Insert the scooter assembly into the same location on the skateboard deck. Press & hold the release lever while sliding the scooter assembly into place. Be sure the release lever is securely locked.




### INSERT THE REMOTE

Insert the remote into the top of the scooter assembly. When using the scooter this will act as the battery indicator, and enable the throttle and brakes.



# ADJUST BRIDGE


Use the wrench to rotate it clockwise to make it hard and counter clockwise to make it soft.



# CONTROLS AND PAIRING


## ATTACHING THE HANDLEBARS

Attach the handlebars by placing them into the appropriate sockets and twisting them in the correct direction.



## TURNING YOUR DEVICE ON/OFF


**Power ON:** Take the skateboard out of the box and place it flat on the floor. Press the power button (located on the underside of your device). The skateboard should beep once, indicating the device is powered on.




**Power OFF:** Press the power button.

## PAIR THE REMOTE WITH THE SWITCH


1. Power on the Skateboard.
2. Press and hold the power button for 5 seconds until you hear the skateboard beep. This will indicate it is in pairing mode.
3. On the remote, press and hold the power button for 3 seconds to enter pairing mode with the skateboard. The indicator light will change from a solid green to a flashing green. This will indicate that pairing is successful. The skateboard will stop beeping when pairing is complete.



Turn on the Skateboard press and hold for 5 seconds into pairing mode.



Turn on the remote, press and hold for 3 seconds.



Both LEDs start flashing, pairing proces is complete.

4. If pairing is unsuccessful, turn both the skateboard and the remote off and follow aforementioned steps to try again.

## SWITCH BATTERY INDICATOR

The Switch battery indicator is located on the Remote itself. To see the battery levels of your Skateboard/Scooter, press the power button on the Remote itself once.

The LED lights indicate battery levels for the Skateboard. Please refer to the diagram below. When the battery level is low, the LED light will flash, indicating the device should be charged.

	Battery level is between 100-70%.
	Battery level is between 70-40%.
	Battery level is between 40-10%. If the battery is lower than 10% the light will begin flashing and must be charge immediately.

## REMOTE BATTERY INDICATOR

The Remote battery indicator is located on the Remote itself. The LED light will indicate battery levels for the remote. Please refer to the diagram below. When the battery level is low, the LED light will flash, indicating the remote should be charged.

	FLASHING below 25%.
--	---------------------

# BEFORE RIDING

## WARNING

Any Switch that does not work properly can cause you to lose control and fall. Do not ride a Switch with a part that is damaged; replace the damaged part before riding.

It is important that you fully understand all elements of your Switch. If these elements are not used correctly, you will not have full control of your Switch. Before you ride, learn the functions of the various mechanisms on your scooter.

Practice using these elements of your Switch at slower speeds in a flat, open area before taking the Switch out in public areas.

### PRE-RIDE CHECKLIST

Ensure that your Switch is in proper working order each and every time you ride. If a part of the scooter does not function correctly, please contact our Customer Support Center.

- Ensure the battery is fully charged before riding your scooter.
- If the Switch is not to be used for an extended period of time, you may need to recharge the battery every 2 months to maintain the battery life.
- Please wear all appropriate safety and protective gear as previously mentioned in the User Manual before operating your Switch.
- Make sure to wear comfortable clothes and flat closed-toe shoes when operating your Switch.
- Please carefully read the Operation Manual, which will assist in explaining the basic working principles and provide tips on how to best enjoy your experience.

# SAFETY PRECAUTIONS

The first rule in safe riding is to use common sense.

Different localities and countries have different laws governing riding on public roads, and you should check with local officials to ensure you are complying with these laws.

Hover-1 is not liable for tickets or violations given to riders who do not follow local laws and regulations.

- For your safety, always wear a helmet that meets CPSC or CE safety standards. In the event of an accident, a helmet can protect you from serious injury and in some cases, even death.
- Obey all local traffic laws. Obey red and green lights, one-way streets, stop signs, pedestrian crosswalks, etc.
- Ride with the traffic, not against it.
- Ride defensively; expect the unexpected.
- Give pedestrians the right-of-way.
- Do not ride too close to pedestrians and alert them if you intend to pass them from behind.
- Slow down at all street intersections and look to the left and right before crossing.

Your Switch is not equipped with reflectors. It is not recommended that you ride in conditions of low visibility.

If you are riding your scooter in low-visibility conditions, ensure you are wearing bright, reflective clothing.

## **WARNING**

When you ride in low-visibility conditions such as fog, dusk, or night, you might be difficult to see, which could lead to a collision. To increase your level of safety, be sure wear bright, reflective clothing when riding in poor lighting conditions.

Think about safety when you ride. You can prevent many accidents if you think about safety. Below is a helpful checklist for riders.

## SAFETY CHECKLIST

- Do not ride above your skill level. Ensure you have had enough practice with all functions and features of your Switch.
- Do not ride too fast – with increased speed comes increased risk. If you are moving at a higher speed, small bumps can turn into large impacts, leading to a higher risk of injury if an accident occurs.
- Do not ride with pets.
- Before stepping on your Switch, make sure it is placed flat on level ground and the power is on.
- Do not try to open or modify your Switch. Doing so, voids the manufacturer warranty and may cause your Switch to fail, resulting in injury or death.
- Do not use the Switch in a manner that would put people or property in danger.
- If you and your friend(s) are riding Switch scooters together, be sure to keep a safe distance between each other to prevent collisions, property damage, serious injuries or even death.
- Be sure to keep your feet on the scooter at all times. Moving your feet off your scooter while driving is dangerous and may cause the scooter to stop or veer sideways.
- Do not operate the Switch while under the influence of drugs and/or alcohol.
- Do not operate the Switch when you are restless or sleepy.
- Use your best judgment to keep yourself out of dangerous situations with your Switch.
- Do not ride your Switch off of curbs, ramps, or attempt to operate in a skate park, empty pool, or in any way similar to a skateboard. Misuse of your Switch, voids the manufacturer warranty and may lead to injury or damage.
- Do not abuse your Switch, doing so can damage your unit and cause failure to the operating system which may lead to injury. Physical abuse, including dropping your Switch, voids the manufacturer warranty.

- Do not operate in or near puddles of water, mud, sand, stones, gravel, debris or near rough and rugged terrain.
- The Switch can be used on paved surfaces that are flat and even. If you encounter uneven pavement, please lift your Switch over and past the obstruction.
- Do not ride in inclement weather: snow, rain, hail, sleet, on icy roads or in extreme heat or cold.
- Bend your knees when riding on bumpy or uneven pavement to absorb the shock and vibration and help you keep your balance.
- If you are unsure if you can safely ride on a specific terrain, step off and carry your Switch. ALWAYS BE ON THE SIDE OF CAUTION.
- Do not attempt to ride over bumps or objects greater than ½ in. even when prepared and bending your knees.
- PAY ATTENTION - look at where you are riding and be conscious of the road conditions, people, places, property and objects around you.
- Do not operate the Switch in crowded areas.
- Operate your Switch with extreme caution when indoors, especially around people, property, and narrow spaces.
- Do not operate the Switch while talking, texting, or looking at your phone.
- Do not ride your Switch where it is not permitted.
- Do not ride your Switch near motor vehicles or on public roads.
- Do not travel up or down steep hills.
- The Switch is intended for use by a single individual, DO NOT attempt to operate the Switch with two or more people.
- Do not carry anything while riding the Switch.
- Individuals with lack of balance should not attempt to operate the Switch.
- Pregnant women should not operate the Switch.

- Young children and the elderly should not operate the Switch.
- At higher speeds, always take into consideration longer stopping distances.
- Do not attempt to jump on or off your Switch.
- Do not attempt any stunts or tricks with your Switch.
- Do not ride the Switch in dark or poorly lit areas.
- Do not ride the Switch near or over potholes, cracks or uneven pavement or surfaces.
- Do not operate your Switch off-road.
- Do not turn sharply, especially at high speeds.
- Do not exceed the maximum or minimum weight limits.
- Avoid driving the Switch in unsafe places, including near areas with flammable gas, steam, liquid, dust, fiber, which could cause fire and explosion accidents.
- Do not operate near swimming pools or other bodies of water.

 **WARNING:**

To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water; always wear shoes, and never allow more than one rider.



# RIDING YOUR SWITCH

**FAILURE TO FOLLOW ANY OF THE FOLLOWING SAFETY PRECAUTIONS CAN AND MAY LEAD TO DAMAGE TO YOUR SWITCH, VOID YOUR MANUFACTURER WARRANTY, LEAD TO PROPERTY DAMAGE, CAUSE SERIOUS BODILY INJURY, AND CAN LEAD TO DEATH.**

## **OPERATING YOUR SWITCH**

Make sure the Switch is fully charged before the first initial use. Before turning on your Switch, ride it like a normal kick scooter or skateboard to get comfortable with the Switch before using it with the motor.

When comfortable riding, power it on. For the motor to activate, you must first start riding and then push the throttle down.

To slow down the scooter, push the electric brake down. This will stop the motor and slow you down.

The Switch is equipped with a built-in 90 Watt Brushless Motor which allows you to accelerate (up to 9 mph) and decelerate.

To turn, use the handlebars or lean gently in the direction you wish to turn.

The Switch can be operated manually if you do not wish to use the motor.

As you get comfortable on the Switch, you will notice it becomes easier to maneuver. Remember at higher speeds, it is necessary to shift your weight to overcome the centrifugal force.

Bend your knees if you encounter bumps or uneven surfaces, then dismount and carry your Switch to a safe operating surface.



## **WARNING**

Do not turn sharply or at high speeds to avoid danger. Do not turn or ride quickly along slopes, as it may cause injury.

## WEIGHT AND SPEED LIMITATIONS

Speed and weight limits are set for your own safety. Please do not exceed the limits listed here in the manual.

- Maximum Weight: 132 lbs
- Minimum Weight: 44 lbs
- Maximum Speed: Up to 9 mph (used as an e-scooter)

### **WARNING**

Overweight exertion on the Switch may increase possibility of injury or product damage.

## OPERATING RANGE

The Switch can travel a distance up to 6 miles on a fully charged battery in ideal conditions. The following are some of the major factors that will affect the operating range of your Switch.

- **Terrain:** Riding distance is highest when riding on a smooth, flat surface. Riding uphill and/or on rough terrain will reduce distance significantly.
- **Weight:** A lighter user will have further range than a heavier user.
- **Ambient temperature:** Please ride and store the Switch under recommended temperatures, which will increase driving distance; battery life, and overall performance of your Switch.
- **Speed and Riding Style:** Maintaining a moderate and consistent speed while riding produces maximum distance. Traveling at high speeds for extended periods, frequent starts and stops, idling and frequent acceleration or deceleration will decrease overall distance.

# SAFETY ALERTS

While riding your Switch, if there is a system error or an illegal operation occurred, the Switch will prompt the user in a variety of ways.

The following are common occurrences where you will see Safety Alerts. These notices should not be ignored, but appropriate action should be taken to correct any illegal operation, failure or errors.

- Prohibited riding surfaces (uneven, too steep, unsafe, etc.)
- Battery voltage is too low.
- The Switch is still charging.
- Overheating, or motor temperature is too high.
- If the system enters protection mode, the alarm indicator will light up. This typically occurs when the battery is about to run out of power.
- If the motor is blocked, the Switch will stop after 3 seconds.
- When the battery level has depleted below protection mode, the Switch motor will power off after 15 seconds.

While sustaining a high discharge current during use (such as riding up a steep slope for a long period of time), the Switch motor will power off after 15 seconds.

# CHARGING YOUR SWITCH

## CHARGING THE SWITCH

- Ensure that the charging port is clean and dry.
- Make sure that there is no dust, debris or dirt inside the port.
- Plug the charger into a grounded wall outlet.
- Connect the cable with the power supply (100V ~ 240V; 50/60 Hz).
- Align and connect the 1-pin charging cable into the charging port of the Switch. **DO NOT FORCE OR BEND THE CHARGING CABLE INTO THE CHARGING PORT, AS IT MAY CAUSE THE PRONGS TO BEND OR BREAK.**
- The charging indicator light should change to RED, indicating that your Switch is now being charged.
- When the RED indicator light on your charger turns to GREEN, then your Switch is fully charged.
- A full charge may take up to 2.5 hours.
- After fully charging your Switch, unplug the charger from your Switch and from the power outlet.

# BATTERY CARE / MAINTENANCE

## BATTERY SPECIFICATIONS

Battery Type: Rechargeable lithium-ion battery

Charge Time: Up to 2.5 hours

Voltage: 25.2V

Initial Capacity: 2.0 Ah

Working Temperature: 32°F - 104°F

Charging Temperature: 32°F - 104°F

Storage Time: 1 year

Storage Temperature: -4°F - 77°F

Storage Humidity: 5% - 95%

## BATTERY MAINTENANCE

The lithium-ion battery is built into the Switch. Do not disassemble the Switch to remove the battery or attempt to separate it from the Switch.

- When charging the Switch, please use the enclosed 1-pin charging cable or otherwise ensure that the battery charging conditions are met.
- Do not connect or attach the Switch or the battery to a power supply plug or directly to a car's cigarette lighter.
- Do not place the Switch or batteries near a fire, or into direct sunlight. Heating the Switch and/or the battery can cause additional heating, breaking, or ignition of the battery inside the Switch.
- Do not continue charging the battery if it does not recharge within the specified charging time. Doing so may cause the battery to become hot, rupture, or ignite.

To preserve natural resources, please recycle or dispose of batteries properly. This product contains lithium-ion batteries. Local, state, or federal laws may prohibit disposal of lithium-ion batteries in ordinary trash. Consult your local waste authority for information regarding available recycling and/or disposal options.

## WARNING

Failure to follow the safety precautions listed below could lead to serious bodily injury and/or death.

- Do not attempt to modify, change, or replace your battery.
- Do not use your Switch if the battery begins to emit odor, overheats, or begins to leak.
- Do not touch any leaking materials or breathe fumes emitted.
- Do not allow children and animals to touch the battery.
- The battery contains dangerous substances, do not open the battery, or insert anything into the battery.
- Please only use the charger provided by Hover-1.
- Do not attempt to charge the Switch if the battery has discharge or emits any substances. In that case, immediately distance yourself from the battery in case of fire or explosion.
- Lithium-ion batteries are considered to be hazardous materials. Please follow all local, state and federal laws in regards to recycling, handling and disposing of Lithium-ion batteries.

 **WARNING**

SEEK IMMEDIATE MEDICAL ASSISTANCE IF  
YOU ARE EXPOSED TO ANY SUBSTANCE  
THAT IS EMITTED FROM THE BATTERY.

# FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# CARE & MAINTENANCE

- Do not expose the Switch to liquid, moisture, or humidity to avoid damage to the product's internal circuitry.
- Do not use abrasive cleaning solvents to clean the Switch.
- Do not expose the Switch to extremely high or low temperatures as this will shorten the life of the Switch, destroy the battery, and/or distort certain plastic parts.
- Do not dispose of the Switch in fire as it may explode or combust.
- Do not expose the Switch to contact with sharp objects as this will cause scratches and damage.
- Do not let the Switch fall from high places, as doing so may damage the internal circuitry.
- Do not attempt to disassemble the Switch, aside from swapping the front assembly.
- Use only the charger provided by Hover-1.

## WARNING

Avoid using water or other liquids for cleaning. If water or other liquids enter the Switch, it will cause permanent damage to the internal components.

## WARNING

Users who disassemble the Switch scooter without permission will void the warranty.

# WARRANTY

For warranty information, Please visit us at:  
[www.hover-1.com](http://www.hover-1.com)

Manufacturer: DGL Group, Ltd.  
195 Raritan Center Parkway Edison, NJ 08837, USA

Affix Serial Number Label Here:





@RideHover1



@RideHover1



@RideHover1



[www.Hover-1.com](http://www.Hover-1.com)